

# USER GUIDE

**SONIM XP7**

English

**sonim**<sup>®</sup>  
BUILT FOR LIFE™

Copyright © 2015 Sonim Technologies, Inc.

**SONIM and the Sonim logo are trademarks of Sonim Technologies, Inc. Other company and product names may be trademarks or registered trade-marks of the respective owners with whom they are associated.**

### Third Party Trademarks

Google, Android, Google Calendar, Google Now, Google Play and other marks are trademarks of Google Inc.

### Disposal of Old Electrical and Electronic Equipment



The symbol of the crossed-out wheeled bin indicates that within the countries in the European Union, this product, and any enhancements marked with this symbol, can not be disposed as unsorted waste but must be taken to separate collection at their end- of-life.

### Disposal of Battery



Please check local regulations for disposal of batteries. The battery should never be placed in municipal waste. Use a battery disposal facility if available.

### Guideline for Headphone and Earphone



To prevent possible hearing damage, please do not listen at high volume levels for long periods.

**General Information**----- 7

- Phone Models Covered
- Sonim Support Information
- Use the Guide Effectively

**Safety Guidelines**----- 8

- SAR Information
- Avoid High Temperatures
- Personal Medical Devices
- Child Safety
- Emergency Calls

**Battery Usage Guidelines**----- 13

- Battery Usage
- Charging the Battery
- Verifying and Optimizing Battery Usage
- Extend the life of your battery

**Getting Started**----- 15

- What Is In the Box ?
- Phone Specifications
- Your SIM Card
- Inserting the SIM Card

**Your Sonim XP7**----- 17

- Switching On the Phone
- Setting Up Your Phone
- Need for a Google +™ Account
- Touch and Type Operations
- Home Screen
- Key Description
- Home Screen Indicators
- Phone Operations Without SIM Card
- Setting up and Using Lock Screen
- Changing the Wallpaper
- Taking a Screenshot
- Voice Input for Text Entry

**Managing Phone Settings**----- 25

- Time and Date Settings
- Using Glove Mode
- Language Settings
- Mouse/Trackpad
- Display Settings
- Connecting to a PC Through USB
- Viewing Device Details
- Managing Memory Utilized by Applications
- Optimizing Memory Usage
- Using the Torch

**Managing Wireless and Network Settings**----- 30

- Connecting to Wi-Fi Network
- Connecting to Bluetooth Devices
- Optimizing Data Usage
- Activate Airplane Mode
- Setting Up Tethering & Portable Hotspot
- Setting Up Wi-Fi Hotspot
- Activating Bluetooth Tethering
- Setting Up VPN Connection
- Managing Mobile Network

**Managing Security Settings**----- 35

- About Android Security
- Managing Security Settings
- Locking Your Screen
- Anti-Theft Protection
- Encrypting Your Phone Data
- Locking Your SIM Card
- Changing Your SIM PIN
- Making Password Visible
- Device Administrator Settings
- Managing Credential Certificates
- Protecting Your Phone from Harmful Applications

**Managing Personal, Account and System Settings**----- 38

Location Access	Turn on Proximity Sensor
Apps Accessing Your Location	Settings TTY Mode
Backup & Reset Options	DTMF Tones
Managing Accounts	Other Call Settings
Account Sync Options	Call Forwarding
<b>Managing Contacts</b> ----- 41	Call Waiting
Adding a New Contact	Internet Call Settings
View the Contact Details	SIP Accounts
Sending a Message from Contacts	Use Internet Calling
Dialing a Number from Contacts	<b>Sending Messages and E-mails</b> ----- 49
Editing the Contact Details	Sending SMS/MMS Message
Importing SIM Card Contacts to Phone	Managing Message Settings
Exporting Phone Contacts to SIM Card	Deleting Messages
Exporting Phone Contacts to Storage	Setting Up E-mail Accounts
Sharing Contacts Via MMS, Bluetooth, Drive and E-mail	Sending an E-mail from POP3/IMAP Account
Managing Contact Settings	Reading an E-mail
Managing Phonebook Settings	<b>Using the Keyboard</b> ----- 52
Searching Contacts	Enter and Edit Text
Deleting a Contact	Gesture Typing
<b>Managing Calls</b> ----- 44	Keyboard Dictionaries
Making a Call	<b>Push To Talk Services</b> ----- 53
Calling a Number Via People	<b>Using Android™ Applications</b> ----- 54
Answering an Incoming Call	Downloading Android Applications and Media Files
Adding a Contact From Phone Screen	Accessing Gmail™
Viewing All Contacts from Phone Screen	Camera
Viewing Call History	Multimedia Player
Deleting Call History	Calendar
Managing Call Settings	Alarm
Settings	Clock
Setting the Volume	Calculator
Activating Vibrate Mode	Sound Recorder
Setting Up Your Voicemail	<b>Google Search™ and Google Now™</b> ----- 57
Dial Pad Touch Tones	About Google Search™ and Google Now™
Editing Quick Responses	Activate Google Now
Monitoring Fixed Dial Numbers	

Use Google Now  
Voice Search and Action  
Voice Actions

**End User License Agreement— — — — — 58**

License  
Comprehensive 3 Year Warranty  
Warranty Registration Application (Only available on  
Smart phones)  
Our Warranty  
What We Will Do  
Phone Care  
Conditions  
Accessories

**Federal Communication Commission Interference  
(FCC) Statement— — — — — 62**

FCC Statement  
IC Statement  
FOR PORTABLE DEVICE USAGE (<20cm from body/  
SAR needed)

**Index— — — — — 64**



# COMPREHENSIVE 3-YEAR WARRANTY

- Please register your phone at [www.sonimtech.com/register](http://www.sonimtech.com/register), to receive product information and updates. Sonim devices are covered by a 3-Year comprehensive warranty. The embedded battery is covered by a 1-Year limited warranty. For more information related to the warranty, please refer to the warranty section "Comprehensive 3 Year Warranty" on page 58.

Congratulations on the purchase of a Sonim XP7700 mobile phone. This phone is an LTE smartphone enabled and has an intuitive feature-rich user interface, which allows you to make the best use of offered functions.

### Phone Models Covered

This user guide covers Sonim XP7 phone with the model number XP7700. The model name can be seen on backside of the phone.

### Sonim Support Information

For additional product and support information, visit [www.sonimtech.com](http://www.sonimtech.com).

### Use the Guide Effectively

Familiarize yourself with the terminology and symbols used in the guide to help you use your phone effectively.

---

#### SWIPE OR SLIDE

Quickly move your finger across the surface of the screen, without pausing when you first touch. For example, you can slide a home screen left or right to view the other home screens.

---

#### DOUBLE TAP

Tap quickly twice on a webpage, map or other screen to zoom. For example, double-tap a webpage in Browser to zoom in, and double-tap again to zoom out.

---

#### PINCH

In some applications, you can zoom in and out by placing two fingers on the screen at once and pinching them together or spreading them apart.

---

---

#### HOME SCREEN

This is the screen displayed when the phone is in standby mode.

---

#### TOUCH & HOLD

Touch and hold an item on the screen by touching it and not lifting your finger until an action occurs.

---

#### DRAG

Touch and hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position.

---

Please read and understand the following safety guidelines before you use the phone. These guidelines provide details to enable you to operate your phone safely and conform to any legal requirements regarding the use of cellular phones.



Do not use the phone at a refuelling point. Observe restrictions when using radio equipment at fuel depots, chemical plants or where blasting operations are in progress.



Electrical interference may obstruct the use of your phone. Observe restrictions in hospitals and near medical equipment.



Switch off your cellular phone when in an aircraft. Wireless phones can cause interference or danger to an aircraft. In an aircraft, the phone can be used in flight mode.



Do not expose the device to high temperatures (in excess of 55°C).



Adhere to road safety laws. Do not hold/use a phone while you are driving; find a safe place to stop first. Use hands-free microphone while you are driving.



Avoid using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids.



Use only Sonim XP7700 approved charging equipment to charge your phone and avoid damage to your phone.



The symbol of the crossed-out wheeled bin indicates that this product, and any enhancements marked with this symbol, can not be disposed as unsorted waste but must be taken to separate collection at their end-of-life.





Ensure that only qualified personnel install or repair your phone.



The Sonim XP7700 is water-proof and can be submerged to 2 metres for 30 minutes.

- Ensure to close the audio connector and SIM slot properly. This will prevent the deposit of water droplets on the connectors, when the phone is immersed in water.
- Water droplets may condense under the display cover if the phone is immersed in water with significant drop in temperature. This does not indicate water leakage. The droplets will disappear at room temperature.

The Sonim XP7700 is dust-resistant, rugged and shock-resistant. However, it is not dust-proof or unbreakable if subjected to overwhelming impact. For best results and long product life, one should protect the Sonim XP7700 from salt water, dust and strong impacts.

## SAR Information

**The Sonim XP7700 has been certified in compliance with the Government's requirements for exposure to Radio Waves.**

When communicating over the wireless network, the mobile phone emits via the radio frequency waves low levels of radio energy. The Specific Absorption Rate, or SAR, is the amount of RF energy absorbed by the body while using the phone and is expressed in watts/kilogram (W/kg).

Governments around the world have adopted comprehensive international safety guidelines, developed by scientific organizations, for example, ICNIRP (International Commission on Non-Ionizing Radiation Protection) and IEEE (The Institute of Electrical and Electronics Engineers Inc.). These guidelines establish permitted levels of radio wave exposure for the general population.

Tests for SAR are conducted using standardized methods with the phone transmitting at its highest certified power level in all used frequency bands.

### **SAR Data Information for residents in the United States and Canada**

The limit recommended by ICNIRP is 1.6 W/kg averaged over one (1) gram of tissue.

The highest SAR value for the Sonim XP7700 phones when tested by Sonim for use:

- By the ear is 0.64 W/1g.
- Worn on the body is 0.68 W/1g provided that the phone is used with a non-metallic accessory with

the handset at least 1cm from the body, or with the original Sonim accessory intended for this phone and worn on the body.

## HAC Rating

The FCC has created a rating system for cellular phones regarding their HAC-related performance. This rating helps consumers with hearing disabilities to find phones that work well with their hearing aid devices. The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19:20011.

ANSI C63.19 contains two rating standards: an "M" rating from 1 to 4 for hearing aids operating in microphone mode, and a "T" rating from 1 to 4 for hearing aids operating in telecoil mode.

M-Rating stands for Microphone rating and indicates the amount of reduction of RF interference between the telephone and the hearing aid in acoustic coupling mode (also called microphone mode).

Phones rated M3 or M4 meet FCC requirements and generate less interference to hearing devices set in microphone mode. T-Rating stands for telecoil rating and represents inductive coupling with hearing aids that are operating in telecoil mode. A telecoil is a small piece of tightly wrapped wire, built into some hearing aids. While the microphone of a hearing aid picks up all sounds, the telecoil only picks up an electromagnetic signal from the telephone. Thus, users of telecoil-equipped hearing aids are able to communicate over the telephone without the amplification of unwanted background noise.

Phones rated T3 or T4 meet FCC requirements and generate less interference to hearing devices set in telecoil mode.

A combination of M-rating and T-rating defines the final HAC rating and is a deciding factor in selecting cellular phones for people with hearing problems. A HAC compliant phone could be rated:

- M3/T3
- M3/T4
- M4/T3
- M4/T4

These ratings assist hearing device users to find phones that are compatible with their hearing devices. Ratings are shown on the phone's box or label. The ratings are not guaranteed for suitability. The results vary depending on the individual's hearing loss and the immunity characteristics of the used hearing device, i.e. its resistance to interference. The best way to evaluate the suitability of the phone is to try it with the intended hearing aid device.

Sonim XP7700 have been tested for hearing aid device compatibility and complies with the Federal Communications Commission (FCC) requirements. **These devices are rated M4/T4.**

### Avoid High Temperatures

Leaving the device in hot or cold places, such as in a closed car in summer or winter conditions, reduces the capacity and lifetime of the battery. **For the best results, try to use the device between -20°C and +55°C (-4°F and 131°F).** A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

### Personal Medical Devices

Mobile phones may affect the operation of cardiac pacemakers and other implanted equipment. Please avoid placing the mobile phone over the pacemaker, for example in your breast pocket. When using the mobile phone, place it at the ear opposite the pacemaker. If a minimum distance of 15 cm (6 inches) is kept between the mobile phone and the pacemaker, the risk of interference is limited. If you suspect that interference is taking place, immediately turn off your mobile phone. Contact your cardiologist for more information. For other medical devices, consult your physician and the manufacturer of the device. Comply with instructions to switch off the device or deactivate the RF transmitter when required, especially when posted in hospitals and aeroplanes. Equipment used in these places may be sensitive to radio waves emitted from the device and adversely affect their operation. Also, observe restrictions at gas stations or other areas with flammable atmosphere or when close to electro-explosive devices.

### Child Safety

Do not allow children to play with your mobile phone or its accessories. Keep it out of their reach. They could hurt themselves or others, or could accidentally damage the mobile phone or accessories. Your mobile phone and its accessories may contain small parts, which could be detached and create a choking hazard.

### Emergency Calls

Mobile phones operate using radio signals, which cannot guarantee connection under all conditions. Therefore you should never rely solely upon any mobile phone for essential communications (e.g. medical emergencies).

Emergency calls may not be possible in all areas, on all cellular networks, or when certain network services and/or mobile phone features are in use. Check with your local service provider.

## Battery Usage

Sonim XP7700 phone comes with a built-in battery. For any battery related queries, contact Sonim customer support.

### Charging the Battery

The battery delivered with your mobile phone is not fully charged. We recommend you to charge it fully, it may take 4 hours to charge completely.

#### 1 Insert Charger

Insert the charger plug into a power outlet

#### 2 Connect to Phone

The charging port is located at the bottom of the phone, below the back cover. Insert the charging connector to the charging port.

### 3 Charging Animation/Icon

- If the battery is being charged when the phone is switched off, a battery charging animation with current battery level is displayed.
- If the battery is being charged while the phone is switched on, the battery icon on the status bar shows the animation indicating that the battery is being charged.
- After the battery is fully charged the charging animation stops and you can disconnect the charger from the phone.



### Verifying and Optimizing Battery Usage

You can check the battery usage status and also close some applications to save battery power. In the all application screen, select **Settings** (⚙️) > **Device** > **Battery** (🔋).

The current battery level (charging or not charging) is displayed on the top of the screen. The discharge graph on the top of the screen shows the battery level over time since you last charged the device, and how long you have been running on battery power.

The list at the bottom of the screen shows the breakdown of battery usage for individual apps and services. Touch any listed items for more details. The details screen for some apps includes buttons that allow you to adjust

settings affecting power usage, or stop the application completely.



If you stop some apps or services, your device may not work correctly.

### Extend the life of your battery

Follow these tips to extend your phone's battery life.

- If you are not using Wi-Fi, Bluetooth, or GPS, use the **Settings** to turn them off. The GPS setting is located in **Settings > Personal > Location**.
- Set screen brightness to **Auto** and set a shorter Sleep time-out (15seconds). The display settings are located in **Settings > Device > Display**.
- If you are travelling and do not have access to use mobile data or Wi-Fi network, switch to Airplane mode: Press and hold the power key until the Phone options dialog appears. Then touch to enable **Airplane Mode**.

## What Is In the Box ?

The list of items in the Sonim XP7 phone box are:

- Sonim XP7 phone with rechargeable built-in battery
- Quick Start Guide
- Multi-tool
- Wired headset
- USB Data Cable
- Charging adapter

## Phone Specifications

Feature	Description
Dimension	137*72.1*20.8 in.
Weight	280 gm
Camera	<ul style="list-style-type: none"><li>• Front camera - 1MP (Fixed focus)</li><li>• Main camera - 8MP (Auto focus)</li></ul>
Memory	16 GB
Sensors	Accelerometer Proximity Ambient light
Network	LTE: B1/B2/B4/B5/B7/B14/B17 UMTS: 850/900/1900/2100MHz GSM: 850/900/1800/1900MHz


Feature	Description
Wireless	Wi-Fi - 802.11 a/b/g/n/r with hotspot function (Max. 5 connections) Bluetooth: Bluetooth 4.0/BLE (Low energy)
Connectivity	Charger port name: 5pins water-proof magnetic USB2.0 3.5mm headphone jack
Operating system	Android™ 4.4, Kitkat®

## Your SIM Card


The SIM card associates your network services (for example, phone number, data services, and so on) with your phone.

## Inserting the SIM Card


1. Remove screw A using the screwdriver in the multi-tool and remove the headset port cover.



2. Remove screw B using the screwdriver and remove SIM cover.



3. Insert the pin into the pinhole and press inside. The SIM card tray will pop-up. Use the pin to hook into the loop on top of the SIM card tray and remove the tray completely.



4. Insert the SIM card in the tray and return the tray into the slot by pushing it in, make sure the pinhole is aligned next to the headset port.
5. Refix both the covers and screws in place using the screwdriver.

# Sonim XP7 Phone



## Switching On the Phone

Press and Hold the **Power/Lock** key for 2 seconds to Power **ON** the phone.

When the phone is switched on, it tries to register with the network. After successful registration, the name of the service provider is displayed on the **Notification** panel.



Ensure that a valid SIM card is inserted in your phone.

## Setting Up Your Phone

For instructions on using your phone's buttons, charger, battery, and other hardware features, check the printed **Quick Start Guide** provided along with your phone.

The first time you turn on your device, it will take you through the steps to get the set up. You will be prompted to do the following:

1. Choose the language you want your phone to use.
2. Connect to a Wi-Fi network or your cellular data network.
3. Sign-in with your Google Account.

If you have Gmail account, use the same e-mail address and password to sign-in. By signing in, all your e-mail, contacts, calendar events, and other data associated with that account will be synced to your phone. If you have more than one Google Account, you can add them later.

If you do not have a Google Account, you can create one during the setup process. You can also skip this step and create later.

## Need for a Google +™ Account

Your **Google** account lets you organize and access your personal information from any computer or mobile device:

- When you sign in to your phone with your Google account, all the contacts you associate with that account in the People app are automatically backed up. As a result, they are always accessible through your Gmail account.
- Synchronize and back up your e-mails, multimedia files, contact details and events created in your phone to your Google account. You can access the backed up information at any other computer or mobile device when you login with the same google account.
- Protect your personal information as Google accounts are secure, accessible and password protected.
- You can use all the Google services such as maps, navigation, Play Store, Google Now, Google+ and Google Chrome with a single sign-on user name and password.

## Touch and Type Operations

Sonim XP7 is a touch phone. You can use your fingers to manipulate icons, buttons, menus, and other items on the touchscreen. To select or activate a feature or application, touch it.

Other common touch gestures are:

- **Touch & hold:** Touch and hold an item on the screen and do not lift your finger until it responds.

- **Drag:** Touch and hold an icon for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. For example, you can drag to reposition shortcuts on Your Sonim XP7 phone.
- **Swipe or slide:** Quickly move your finger across the surface of the screen, without pausing when you first touch (so you don't drag something instead). For example, you can slide a Home screen left or right to view the other Home screens.
- **Double-tap:** Tap quickly twice on a webpage, map, or other screen to zoom. For example, double-tap a webpage in Browser to zoom in, and double-tap again to zoom out.

## Home Screen

After you complete the phone setup, the home screen is displayed. The home screen is the beginning point to access all the device's features. The home screen can have multiple panels. Swipe to move between the home panels.



## Key Description

Keys	Description
	<b>Back -</b> Opens the previous screens in the working sequence till the home screen is displayed. Once the home screen is displayed it will remain there even when you press the back key.
	<b>Home -</b> Short press on any app: Shows the home screen. Long press: Google Now

Keys	Description
	<p><b>Recent - Short Press:</b> Opens a list of thumbnail images of apps you have worked on recently. To open an app, touch it. To remove any application from this list, swipe the application to left or right.</p> <p><b>Double press:</b> Launches the menu options of any application.</p>

**The Favorites Tray:** is located above the hard key panel on the home screen. The app icons you keep in the tray remain visible on every Home screen panel.

**The Application Menu:** () is always positioned in the centre of the favorites tray. Touch it to view all the installed applications and widgets.

The Alert notification area in the status bar on the top of the display screen provides details about various notifications such as missed call, new messages, alarms, events and software updates.

- To view the notifications, swipe your finger down from the top of the screen.

The **System icons** on the right display the current device status such as wireless and network connection strength, battery level and time.

The **Google Search bar** is just below the status bar and lets you search your phone or the Internet. Touch **Google Search bar** to type your search terms, or to speak and give a voice input.

You can add shortcuts for applications and add widgets on your home screen panel.

## Adding an Application Icon to Home Screen

1. On the home screen, tap on **Apps Menu** () .
2. Swipe left or right to locate the application for which you require a shortcut on the home screen.
3. Touch and hold the application icon and drag it to the home screen.
4. To open an app, tap on its shortcut on the home screen.

## Creating a Folder on the Home Screen

Folder helps you to keep the icons in an organized fashion. To create folders,


1. Touch and hold an icon on the home screen or Applications.
2. Drag and position it on another icon that should be included in the same folder. 20
3. Hold for about 2 seconds. Both the icons are grouped together in an unnamed folder.
4. Tap on the folder. Tap on the name area and give a suitable name.

## Moving an Icon/Folder from the Home Screen

1. Touch and hold the application icon and drag it to the new location.
2. To move it to another home screen, drag it to the side of the screen.

## Removing an Icon/Folder from the Home Screen

1. Touch and hold the application icon. A ( Remove)

- text is displayed on the top of the home screen.
2. Drag the icon and position it on the (  Remove ) text till it turns red.
  3. Drop the icon and it will be deleted from the home screen.



Deleting a downloaded application icon from the home screen will not delete the application. You must go to **Settings > Devices > Apps > Downloaded**, select a particular application and uninstall it.

### Home Screen Indicators

The icons displayed at the top of the screen provides information about the status of the device. The details such as time, battery level, data service, Wi-Fi connectivity and network status are displayed when the phone is in standby mode. Other indicators such as Bluetooth connectivity status, airplane mode, alarm and call forward are displayed, if the feature is activated.

Icons	Description
	Battery level indicator
	Battery charging in progress
	No signal

Icons	Description
	Signal strength
	No SIM card
	Roaming
	4G LTE network connected
	HSPA or UMTS network connected
	GPRS network connected
	EDGE network connected
	Wi-Fi connected
	Bluetooth activated
	Call in progress

Icons	Description
	New E-mail
	FM Radio
	Missed call
	New SMS or MMS
	Alarm activated
	Silent mode activated
	Vibration mode activated
	Flight mode activated
	Error/information notification - attention required
	Screenshot captured

Icons	Description
	Music is played
	Device storage space is running out

### Phone Operations Without SIM Card

You can perform the following operations without inserting a SIM card in your phone.

- Make an emergency call.
- View and modify all settings except few data usage and mobile network related settings.
- Activate and share files through Bluetooth.
- Activate and access the Internet, and all your synced accounts using Wi-Fi connectivity.
- Access your phonebook, files, multimedia files, all tools and applications.

22

### Setting up and Using Lock Screen

You must lock your phone screen to protect it from unauthorized access.

1. From the Home screen or **Apps Menu**, tap on **Settings** ().
2. Scroll down and tap on **Security** () , located under **Personal** settings.
3. Tap on **Screen lock** and select one of the following options to configure lock screen:

- **None:** Disables the screen lock.
- **Slide:** When the screen is locked with the slide, slide your finger across the screen to unlock it.
- **PIN:** Provide your PIN value (minimum four numbers) to set up PIN lock. When the screen is locked with PIN, provide your correct PIN value to unlock the screen.
- **Pattern:** Draw your pattern to setup the pattern lock. When the screen is locked with pattern, provide the correct pattern to unlock it.
- **Password:** Provide your password to setup the password lock. When the screen is locked with password, provide your correct password to unlock the screen.
- **Face Unlock:** You will be asked to set a back-up pin or pattern screen lock after you setup face unlock. Once it is set up, you can unlock your device just by looking at it.

When the phone screen is locked, you can answer an incoming call, without unlocking the screen.

Touch the **center** icon (  ) and slide over one of these icons:

Icons	Description
	Answer the call.
	Disconnect the call.



Disconnect the call and respond with a default text message from a list of response text messages.

## Changing the Wallpaper

You can set an image or a photo stored in your phone as your home screen wallpaper. To change the wallpaper,

1. Tap and hold on the Home screen. Choose **Wallpapers** option.
2. Select from one of the following Wallpaper collections:
  - **Gallery:** includes the Photos taken using phone's camera, screenshots and downloaded photos.
  - **Live Wallpapers:** includes animated wallpapers.
  - **Photos:** includes photos saved in Google account like Picasa web Album.
  - **Wallpapers:** includes images that are pre-bundled with the phone.

## Taking a Screenshot

You can take the screenshot of the current screen and it is stored in your phone's gallery. To take a screenshot:

1. Ensure that the image to be captured is displayed on the screen.
2. Press the **Power** button and **Volume** down button simultaneously. The screenshot is captured and stored in the gallery.

3. A **screenshot capture** icon (  ) is also displayed in the status bar.

The screenshot is saved automatically in the **Gallery**.

### Voice Input for Text Entry

You can use voice input to enter text by speaking. This feature uses Google's speech-recognition service. It is necessary to have data connection on a mobile or Wi-Fi network to use it.

## Time and Date Settings

You can set and display the date and time on the phone. You can also select the display format.

- From the Home screen or **Apps Menu**, tap on **Settings** () .
- Scroll down and tap on **Date & Time** () , located under **System** settings.
- Select one of the following options to configure **Date & Time**:
  - To synchronize the date and time with the network provided time, enable **Automatic date and time**.
  - To synchronize the time zone with the network provided time zone, enable **Automatic time zone**.
  - To set the date manually, tap on **Set date**. Scroll and select the day, month and year. Tap on **Done**.
  - To set the time manually, tap on **Set time**. Scroll and select the hour and minute. Tap on **Done**.
  - To set the time zone, tap on **Select time zone**. Scroll and select your time zone.
  - To set the clock to 24-hour format enable **Use 24-hour format**.
  - To set your preferred date format, tap on **Choose date format**. The date formats supported are Regional (the standard format supported by that country or region, MM DD YYYY, DD MM YYYY, YYYY MM DD with / as the date separator).

## Using Glove Mode

The XP7 phone is equipped with a glove touch screen. In order to be able to use the glove mode, enable the glove mode on the device.

- From the Home or **Apps Menu**, tap **Settings** () .
- Scroll down and tap on **Accessibility** () located under **System**.
- Go to **Glove mode** and check the box.

The glove mode is enabled and you can use the touch screen with the gloves.

## Language Settings

You can set the phone's language to any of the languages displayed in the language list.

- From the Home or **Apps Menu**, tap **Settings** () .
- Scroll down and tap **Language & input** () , located under **Personal** settings.
- Go to **Language** and select any language from the list as your preferred language.

The following languages can be set as a preferred language:

- English
- Spanish

All the menu items and user feedback messages will get displayed in the set language.

## Spell checker

Allow the user to select from potential corrections on the

misspelled word while typing the text.

## Personal Dictionary Settings

The default keyboard input language is set to English/ (United States). This will be as per the language set.

## Speech Settings

- The Speech engine is set to **Google Text-to-speech**. To change the **Google Text-to-speech** engine settings, tap on **Settings** icon (  ) provided next to the engine.
- Tap on **Speech rate** to set the Speech input rate to a comfortable speed.
- Tap on **Listen to an example** to play a short demonstration of speech synthesis.
- Displays the language set for speech output.

## Mouse/Trackpad

Minimize or Maximize the pointer speed as per comfort level.

## Display Settings

You can activate and modify the display settings.

1. From the Home screen or **Apps Menu**, tap on **Settings** (  ).
2. Set the following options to configure your phone's display:
  - **Brightness:** Set the brightness of the phone display. It is recommended to set to Auto so that the display brightness is adjusted automatically based on

the brightness of the surroundings. This will also optimize the battery power consumed.

- **Wallpaper:** Set the wallpaper for your home screen. You can select from one of the following Wallpaper collections:
  - **Gallery:** includes photos and screenshots taken using the phone's camera.
  - **Live Wallpapers:** includes animated wallpapers.
  - **Photos:** includes photos taken from phone camera, downloaded, and the photos synced from google account.
  - **Wallpapers:** includes images that are pre-bundled with the phone.
- **Auto-rotate screen:** Allows you to enable or disable automatic screen rotation
- **Sleep:** Set the sleep time so that the backlight turns off after specified time of phone inactivity. This setting will also help you to optimize battery power.
- **Daydream:** Enable this option to activate to daydream while docked, charging or either after specified time of phone inactivity. You can set the screen saver to one of the following options.
 

After you turn Daydream on, choose what your device will display from the list below. You can always test your Daydream by choosing **Start Now**" at the bottom of the screen.

  - **Clock:**
    1. Displays the device's digital or analog clock.
    2. Touch the **Settings** icon next to **Clock** to

choose between analog and digital. You can also set the **Clock** to **Night mode** so the screen is not very bright.

- **Colors:** Displays changing colors on the screen.

- **Photo Frame:**

Shows a slideshow of photos from your device

- Touch the additional settings icon next to **Photo Frame** to choose what photos are displayed.

- **Photo Table:**

- Shows a collage of photos from your device.
- Touch the additional settings icon next to **Photo Table** to choose what photos are displayed.
- Once the Daydream starts, you can touch and hold an image to move it around the screen, or swipe it away to hide it.



Your **Daydream** will start after your device goes into **Sleep mode**, but it does not display if you shut off your screen using the power button. Once your device is charging or in a dock, let it go into **Sleep mode** on its own.

By default, your device may only **Daydream** when it is docked. If you want your device to Daydream whenever it is plugged in, make sure to set **When to Daydream** as **Either** or **While charging**.

#### Set wait time for Daydream (Sleep mode):

1. Open your device's **Settings** menu .

2. Touch **Device > Display**.

3. Touch **Sleep**.

#### Select when to Daydream (docked or charging):

1. Open your device's Settings menu.

2. Touch **Device > Display**.

3. Touch **Daydream**.

4. At the bottom of the screen, touch **When to Daydream**.

- **Google Photos:**

1. Displays photos from device and Google Photos.
2. Touch the additional settings icon next to Google photos to choose what photos are displayed.

- **Font size:** Set the font size to one of the following options:

- Small, Normal, Large and Huge.

- **Press Home wake up:** When the phone display is off or in sleep mode, you can activate the display by pressing the home key.



The LED light on the top of the phone blinks for all the notifications.

#### Connecting to a PC Through USB

When the phone is connected to the computer via an USB cable, You will see a **USB** icon () and a notification **Connected as a media device** appear at the top of the screen.

Tap on that **Notification**, you will see two options:

- **Media Device (MTP):** It lets you transfer media files on windows, or using android file transfer on Mac.
- **Camera (PTP):** It lets you transfer photos using camera software and transfer any files on computers that do not support MTP.

### USB Tethering:

To share your phone Internet connection with computer using USB tethering, follow these steps:

Select **Settings > More > Tethering and Portable hotspot > Enable USB Tethering**.

User should have mobile data or connected to Wi-Fi.

When the connection is made, you'll see one of the following notifications:

- USB or portable hotspot active
- Multiple tethering or hotspot connections active

To stop sharing your data connection, uncheck USB tethering or disconnect the USB cable.

### Viewing Device Details

To view the device details such as system updates, status, model number, Android version, Kernel and baseband versions.

1. From the Home screen or **Apps Menu**, tap on **Settings** (⚙️).
2. Scroll down and tap on **About phone** (📄) located under **System** settings.

### Managing Memory Utilized by Applications

You can manage apps beyond installing, opening, and using them. But there may be times when you want to know more about what's happening behind the scenes in order to manage your storage in a better way.

You can use the **Apps** screen to adjust several aspects of the way your device uses memory. To view these settings, follow these steps:

1. From the Home screen or **Apps Menu**, tap on **Settings** (⚙️).
2. Scroll down and tap on **Apps**, located under **Device settings**. The following tabs are displayed.
  - **Downloaded:** Displays apps you have downloaded from **Google Play store** or other sources.
  - **Running:** Displays all apps, processes, and services that are currently running or that have cached processes, and how much RAM utilized by each application. The graph at the bottom of the **Running** tab shows the total RAM in use and the available RAM to use. Touch **SHOW CACHED PROCESSES** or **SHOW RUNNING SERVICES** to switch back and forth.
  - **All:** Displays all applications that are pre-bundled with Android and downloaded from Google Play Store or other sources.

28

### Optimizing Memory Usage

You can optimize your phone's memory by performing the following tasks.

- Uninstall apps that are not required.

- Delete unwanted files that are downloaded or created.
- Transfer files to your computer that would be required for later use.
- Remove offline content from Google Play and stream it via a Wi-Fi or mobile network.

## Using the Torch

You can enable the Torch in 2 different ways:

### From Home Screen:

1. Add the LED flashlight widget to the homescreen.
2. Tap on the **Torch** icon (  ) to turn on the torch.
3. Torch can be turned off by tapping on **Torch** icon.

### From Lock Screen:

- Tap on the **Torch** icon (  ) to enable or disable the torch.



If Torch is turned **ON** from Home screen, it can be turned **OFF** from Lock screen by tapping on Torch icon present in lock screen and vice versa.

## Connecting to Wi-Fi Network

Wi-Fi is a wireless network technology that can provide Internet access at distance upto 100 feet, depending on the Wi-Fi router and surroundings.

You can access Internet when you connect your XP7 to a Wi-Fi network. To connect your phone to a Wi-Fi network,

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Enable **Wi-Fi**, located under **Wireless & Networks** settings.
3. Tap on **Wi-Fi**. A list of Wi-Fi routers present within your phone's accessible range are displayed.
4. Tap on your preferred network. Enter the password (if it is a secured network) and tap on **Connect**. To verify the password before connecting, enable **Show password**.



It is always recommended to make your Wi-Fi router secure and also to connect your phone to a secure network.

## Adding a New Network

To add a new Wi-Fi network,

1. In the **Wi-Fi settings** screen, touch Add network button ()
2. Enter the following details:
  - **Network SSID:** The wireless network ID.
  - **Security:** Set the security type to None, WEP, WPA/WPA2 PSK, 802.1x EAP.

3. Enable **Show Advanced Options** to set the **Proxy details** and **IP settings**.

## Editing a Network

1. Touch and hold the connected network.
2. Select **Modify Network**. The network setting details such as connection status, signal strength, link speed, security type, IP address and password are displayed.
3. Tap on **Save** to Save the settings or **Cancel** to exit to the previous screen.

## Forgetting a Network

1. Touch and hold the connected network.
2. Select **Forget Network**.

The selected network gets disconnected from Wi-Fi and prompts for the password if the user tries to get connected to the same network again.

## Enabling WPS For your Router

To setup a secure Wi-Fi network,

Tap **WPS Push button** () in the Wi-Fi network settings and press the **WPS** button in your router, when prompted.

## Connecting to Bluetooth Devices

Bluetooth is a short-range wireless communication technology used to communicate between the devices

over a distance of about 8 meters.

Using Bluetooth, you can perform the following tasks:

- Transfer media files and contacts between mobile devices connected using Bluetooth.
- Access Internet through a Bluetooth device.
- Use Bluetooth connected headphones for playing media file.

### Pairing a Bluetooth Device

To activate Bluetooth and pair your XP7 phone with other Bluetooth devices:

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Enable **Bluetooth**, located under **Wireless & Networking** settings.
3. Tap on **Bluetooth**.
4. Tap on **Search for devices**. A list of accessible Bluetooth devices are displayed.
5. Tap on your preferred device.
6. Confirm the pass key in the other device and tap on **Pair** in your phone.

The device is displayed in the **Paired devices** list.

### Editing Paired Bluetooth Device Settings

1. Tap on **Settings** icon () located next to the preferred paired Bluetooth device.
2. Tap on **Rename** option to rename the paired the bluetooth Device.

3. Tap on **Unpair** option to unpair it.
4. Enable **Media audio** to connect the Bluetooth device for listening to media files.
5. Enable **Internet access** option to access the Internet.

### Optimizing Data Usage

Data usage refers to the amount of data used by your phone during Internet access. The data usage charges are dependent on the plan provided by your service provider.

To monitor your data usage, adjust your data usage settings.

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Tap on **Data Usage**, which is located under **Data usage** () settings.
3. Turn on **Mobile Data** to access Internet using your mobile network
4. Enable **Set mobile data** limit to preset your data usage limit and to set an alert before reaching the preset limit.
5. Drag the red bar to set the **Data usage limit**.

Mobile data will get disabled once you reach this limit. You will not be able to access the Internet. You receive a notification once you reach the set data usage limit

6. Drag the orange bar to set data usage warning so that you will get an alert before reaching your set data usage limit.

## Activate Airplane Mode

When your phone is set to airplane mode, you will not have network connectivity or mobile data connectivity. But you can access your camera, media files and other features that do not require mobile data connectivity.

To activate the airplane mode.

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Tap on **More** located under **Wireless & Networks** settings.
3. Enable **Airplane mode**.

## Setting Up Tethering & Portable Hotspot

You can share your device's Internet connection with a computer or with other devices. You can also turn your mobile device into a portable Wi-Fi hotspot and share its Internet connection with up to 5 other devices at once.

To Activate USB Tethering,

Connect your phone to computer using a USB cable

1. From the Home screen or **All Apps**, tap on **Settings** ()
2. Tap on **More** located under **Wireless & Networks** Settings.
3. Tap on **Tethering & Portable hotspot**.
4. Enable **USB tethering**.

## Setting Up Wi-Fi Hotspot

You can turn your phone with mobile data into a portable Wi-Fi hotspot for up to 5 other devices, such as a laptop

and computer.

1. Tap on **More** located under **Wireless & Networks** settings.
2. Tap on **Tethering & Portable hotspot**.
3. Tap on **Set up Wi-Fi Hotspot**.
4. Enter **Network SSID**, **security details** and **password** and tap on **Save**.

## Activating Wi-Fi Hotspot

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Tap on **More** located under **Wireless & Networks** settings.
3. Tap on **Tethering & Portable hotspot**.
4. Enable **Portable Wi-Fi hotspot**.

## Activating Bluetooth Tethering

You can set up your phone to share its Internet connection using Bluetooth.

1. Go to **Settings** () ,turn on **Bluetooth**.
2. Pair your phone with the other device you want to share an Internet connection with.
3. Set up the other device to get its network connection via Bluetooth.(Refer to the document that comes with the device).
4. Go back to **Settings** menu.
5. Tap on **More** located under **Wireless & Networks** settings.

6. Tap on **Tethering & Portable hotspot**.
7. Enable **Bluetooth Tethering**.

### Setting Up VPN Connection

Virtual private networks (VPNs) allow entry into secured local networks from the outside. Corporations, schools, and other institutions use VPNs to grant access to local network resources when people are not on campus or connected to a wireless network..

#### To setup a VPN connection,

1. From the Home screen or **Apps Menu**, tap on **Settings** (  ).
2. Tap on **More** located under **Wireless & Networks** settings.
3. Tap on **VPN**.

Ensure lock screen PIN or password is set.

4. Tap on **Add network** icon (  ). Edit **VPN profile** screen is displayed.
5. Enter the following details:
  - **Name:** VPN connection name.
  - **Type:** Select the connection type.
  - **Server address:** Address of the secure server for connection.
  - **PPP encryption:** Enable to perform a secure point-to-point encryption between your device and the VPN server.
  - Select **Advanced** to enter DNS server details.

### Connecting to a VPN Network

- Tap on the required VPN name from the list of VPN networks configured.
- Enter the required credentials.
- Tap on **Connect**.

When the phone is connected to the VPN network status icon and notification are displayed continuously in the home screen.

### Editing VPN Network Details

- Touch and hold the required VPN profile to be edited, from the list of VPN's configured.
- Tap on **Edit profile**.
- Modify the required information.
- Tap on **Save** to save the changes.

### Deleting a VPN Network

To delete a VPN profile from the VPN screen,

1. Touch and hold the VPN profile to be deleted from the list of VPN's configured.
2. Tap on **Delete profile**.

### Managing Mobile Network

To view and modify your mobile network settings,

1. From the Home screen or **Apps Menu**, tap on **Settings** (  ).
2. Tap on **More** located under **Wireless & Networks**

settings.

3. Tap on **Mobile network**.
4. Enable **Data enabled** to access the Internet using your mobile network.
5. Enable **Data roaming** to have network connectivity when you are in a roaming network.
6. Tap on **Access Point Names** to view, add and edit the network access points.

## About Android Security

Android takes a multi-layered approach to the security.

- **Prevent:** Apps in Google Play are scanned continuously to block harmful apps and policy violators. You can also choose to have apps installed from other sources verified.
- **Control:** App **sandboxes** keep apps from accessing other parts of your device's operating system, or each other, unless you give permission at installation. Screen lock and encryption helps to prevent an unauthorized access to the entire device.
- **Defend:** Once identified, dangerous apps can be removed remotely.

## Managing Security Settings

You can activate and protect your phone from unauthorized access by configuring the security settings.

1. From the Home screen or **Apps Menu**, tap on **Settings** (.
2. Tap on **Security** located under **Personal** settings. Enable the required settings to preferred security settings from the below options.

## Locking Your Screen

1. Tap on **Screen lock** and select one of the following options to configure lock screen:
  - **None:** Disables the screen lock.
  - **Slide:** When the screen is locked with the slide, slide your finger across the screen to unlock it.
  - **Pattern:** Draw your pattern to setup the pattern

lock. When the screen is locked with pattern, provide the correct pattern to unlock it.

- **PIN:** Provide your PIN value (minimum four numbers) to set up PIN lock. When the screen is locked with PIN, provide your correct PIN value to unlock the screen.
- **Password:** Provide your password to setup the password lock. When the screen is locked with password, provide your correct password to unlock the screen.
- **Face Unlock:** You will be asked to set a back-up pin or pattern screen lock after you setup face unlock. Once it is set up, you can unlock your device just by looking at it.

When the screen is locked, you can answer an incoming call, without unlocking the screen.

Touch the **center** icon () and slide over one of these icons:

Icons	Description
	Answer the call.
	Disconnect the call.
	Disconnect the call and respond with a default text message from a list of quick response text messages.

2. The screen gets locked automatically as per

**Automatically lock** option set.

3. Enable **Power button instantly Locks** option to lock the screen when immediately you press the power button.
4. Check **Enable Widgets** to add and view widgets on the lock screen.
5. Enable **Show Owner Info on lock screen** in **Owner Info** option to display your specific owner info on the lock screen. You can modify this detail whenever required.

### Anti-Theft Protection

An Anti-theft protection setting is provided in the phone which will protect the user data and user-affiliated data when your device is stolen.

Anti-theft protection setting also provides the following features who has an authorized account

1. Remotely locate a device through an authorized account.
2. Remotely lock a device through an authorized account.
3. Remotely Wipe Out the user-data.
4. Prevent Flashing unauthorized software.

If the Gmail account has been configured in the device, which is lost, the user can log into Android Device Manager (ADM) with the same Gmail id as in the device and erase the content using ADM command.



Anti-theft protection setting prevents the device from flashing it using any other tool.

1. From the **Home** screen or **Apps Menu**, tap on **Settings** (⚙️).
2. Tap on **Security > Protect Your Phone > Select Lock**.
3. Select one of the following options to configure anti-theft protection lock:
  - **None:** Disables the anti-theft protection lock.
  - **PIN:** Provide your PIN value (minimum four numbers) to set up PIN lock. When the anti-theft protection is enabled with the PIN, provide your correct PIN value to disable the lock or to factory reset the device.
  - **Password:** Provide your password to setup the password lock. When the anti-theft protection lock is enabled with password, provide your correct password to disable the lock or factory reset the device.

Once the anti-theft protection is configured, your phone is prevented from modifying their key protection features.

### Encrypting Your Phone Data

You can encrypt your accounts, phone settings, downloaded applications, contacts, messages data and media files.

- Tap on **Encrypt phone** to encrypt your phone data. You will require a numeric PIN or password to decrypt the data when ever you switch ON the phone.



Encryption takes at least an hour depending on the amount of data to be encrypted. Hence, ensure that your phone is fully charged before you encrypt it.

## Locking Your SIM Card

You can activate and set a SIM lock.

1. Tap on **Setup SIM/RUIM card lock**.
2. Enable **Lock SIM card**.

To disable this option you must enter your SIM lock PIN.

## Changing Your SIM PIN

1. Tap on **Change SIM PIN**. Enter the old pin and tap **OK**.
2. Enter the new PIN and re-enter the same value when asked. Tap **OK**.

## Making Password Visible

Enable the **Make passwords visible** option to view the password while entering.

## Device Administrator Settings

To activate device administrator, tap on **Device Administrators** > enable **Launcher**.

You can enable device administrators and allow the App launcher to perform the following tasks:

- Erase the phone's data without warning by

performing factory data reset.

- Change the screen unlock password.
- Set specific password rules.
- Monitor the number of screen-unlock attempts and alert if required.
- Regulate screen lock pattern and time.

## Managing Credential Certificates

You can view, install, verify and manage the certificates installed in your phone.

- Tap on **Trusted Credentials** to view the verified system and user certificates.
- Tap on **Install from Storage** to install the certificates from storage.

## Protecting Your Phone from Harmful Applications

Some applications can harm your device. It is recommended to verify apps in order to help prevent harmful software from being installed on your device To prevent installation of application from unknown sources, disable the option **Unknown sources**.

If you want to install applications from unknown sources, enable **Verify apps** under **Settings** > **Security**, to verify if the application is safe for installation.

## Location Access

If you enable Location services, your location information is displayed in all your accounts.

1. From the Home screen or **Apps Menu**, tap on **Settings** (⚙️).
2. Tap on **Location** located under **Personal** settings.
3. Turn on **Location**.
4. Set one of the following modes:
  - **High accuracy:** High accuracy mode uses GPS, Wi-Fi and mobile networks to get the highest-accuracy location for your device. It uses assistance data to help estimate your location faster and more accurately.
  - **Batter saving:** Battery saving mode allows your device to estimate your location using low battery-intensive location sources, such as Wi-Fi and mobile networks. It uses assistance data to help estimate your location faster and more accurately.
  - **Device only:** Device only mode allows your device to estimate your location using GPS. This mode may use more battery power and take longer to determine your location.

When the location information is turned **OFF**, your device location is not shared with any apps.

## Apps Accessing Your Location

You can view and force stop the apps that are accessing or have recently accessed your location.

1. In the **Location** screen, view the list of applications

that are accessing or recently accessed the location data of your phone, under **Recent location requests**.

2. Tap an application to view the application page. You can stop the application or uninstall it.
  - **High battery use:** This app receives location information from sources that may use more battery power.
  - **Low battery use:** This app receives location information from only low battery-intensive sources.

Selecting an app brings you to its App info page, where you can view app permissions and uninstall an app.

## Backup & Reset Options

You can back up data and connect to one or more of your Google accounts using Android backup services. If you need to replace your device or erase its data, you can restore your data for any accounts that were previously backed up.

### To backup your data:

1. From the Home screen or **Apps Menu**, tap **Settings** (⚙️).
2. Tap on **Backup & reset** located under **Personal** settings.
3. Enable the option **Back up my data**.



If you do not have a backup account on your device, you can touch **Backup account** to add an account.

## To erase your device's data:

If you want to erase all your personal data from your device, follow these steps:

1. Go to **Settings**, Tap on **Backup & Reset**.
2. Tap on **Factory Data reset**.
3. Tap on **Reset phone** and tap on **Erase everything**.

All of your data is erased from your device, including your Google Account, any other accounts, your system and app settings, and any downloaded applications.

After resetting your device, you will need to re-enter the same information requested when you first set it up. If you have been backing up your data to a Google Account, an option during the setup process allows you to restore it.

## Managing Accounts

You can link an existing Google account to your phone to organize and access your personal information from any computer or mobile device.

### Adding an Account

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Tap on **Accounts** located under **Account** settings. Tap **Add account**.
3. Select the type of account. You can create a **Corporate**, **Google** or **POP3/IMAP** account.
4. Complete the on-screen instructions.

The Google account will be displayed in the path:  
**Settings > Accounts > Google**.

## Removing an Account

You can remove any account and all information associated with it from your device, including e-mail, contacts, settings, and other data backed up in that account.

To remove an account,

1. Tap on **Settings**.
2. Tap on **Type of account** such as Google.
3. Tap on the **Account** to be selected.
4. Tap on **Menu > Remove account**.

## Account Sync Options

### Configure Auto-Sync for all Apps

To control auto-sync for all apps that use it, open **Settings > Wireless & Networks > Data usage > Menu** and check or uncheck **Auto-sync data**.

If this option is not checked, you may be able to use an app's tool to sync data manually. You can also sync manually to collect messages, e-mail, and other recent information. Leaving auto-sync off can help extend your battery life, but will prevent you from receiving notifications when updates occur.

### Configure Google Account Sync Settings

To adjust a single Google Account's sync settings:

1. Go to **Settings > Accounts > Google**.
  - () Indicates that some or all of an account's information is configured to sync automatically.

- (  ) Indicates that none of an account's information is configured to sync automatically.
2. Tap the account whose sync settings has to be changed.
  3. If your account is set to auto-sync, you can check or uncheck items as needed. If auto-sync is off which is located under **Settings > Data Usage > Options > Auto-sync data**, touch an item to manually sync its data.

### Sync a Google Account Manually

1. Go to **Settings > Accounts > Google**.
2. Tap on the account whose data has to be synced.
3. Tap on **Menu > Sync now**.

You can use the phonebook to maintain phone numbers of your contacts. This feature enables you to add, delete, dial phone numbers, send SMS and MMS messages.

To access the contacts,

From home screen or **Apps Menu**, tap **People** (). The contacts saved in the phonebook are displayed.



You can touch and drag the scroll bar on your phone screen to scroll through the contacts.

### Adding a New Contact

- To add a new contact, tap on **People > Add new contact** (). Enter the contact details and tap on **Done** to save the contact.
- You can also enter a number using the dial pad and tap on **Add to contacts** to add a new contact.

### View the Contact Details

- From Home screen or **Apps Menu**, tap on **People** ().
- Scroll to the required contact and tap the contact, to view the contact details.

### Sending a Message from Contacts

You can send SMS and MMS messages to the contacts.

#### Sending SMS/MMS

- From Home screen or **Apps Menu**, tap on **People** ().

- Scroll to the required contact and tap on the contact and then tap on **Message** icon (), to open the message screen.
- Type the message or tap an Attachment () to attach a multimedia file.
- Tap on **Send** ().

### Dialing a Number from Contacts

- From Home screen or **Apps Menu**, tap on **People** ().
- Scroll to the required contact and tap the contact to view the contact details.
- Tap on the required phone number to dial the contact.

### Editing the Contact Details

- From Home screen or **Apps Menu**, tap on **People** ().
- Scroll to the required contact and tap the contact to view the contact details.
- Tap on **Options** and select **Edit**.
- Edit the required details and tap on **Done**.

### Importing SIM Card Contacts to Phone

- From Home screen or **Apps Menu**, tap on **People** ().
- Tap on **Options** and select **Import/Export**.
- Tap on **Manage SIM card contacts**.

The list of contacts stored in your SIM card is displayed.

4. Tap on the contact to be moved to the phone.

The contact is imported to the phone address book.

### Exporting Phone Contacts to SIM Card

1. From Home screen or **Apps Menu**, tap on **People** ().
2. Tap on **Options** and select **Import/Export**.
3. Tap on **Export to SIM card**.

The list of contacts stored in your phone address book is displayed.

4. Check the contacts to be exported to the SIM.

The contacts are exported to the SIM card.

### Exporting Phone Contacts to Storage

1. From Home screen or **Apps Menu**, tap on **People** ().
2. Tap on **Options** and select **Import/Export**.
3. Tap **Export to storage** and tap **OK** on **Export Contacts** pop-up.

All the contacts are exported to phone's internal storage as .VCF file.

### Sharing Contacts Via MMS, Bluetooth, Drive and E-mail

You can send contact information by MMS, e-mail or

Bluetooth.

1. From Home screen or **Apps Menu**, tap on **People** ().
2. Tap on **Options** and select **Import/Export**.
3. Tap **Share visible contacts**.
4. Select one of the following options to share the contacts and tap **Just Once** to select the transfer mode each time or **Always** to send the contacts using the same method.

- **Bluetooth:** Send the contact details to a Bluetooth device paired with your phone. Select the Bluetooth device to share the contact.
- **E-mail:** Send the contact details as an e-mail message. Ensure to setup your e-mail account before sending e-mail messages. Else you are requested to setup the e-mail account.
- **Messaging:** Send a contact as a multimedia message to any mobile phone.
- **Gmail:** Send the contact details as an e-mail using your configured Gmail account.
- **Drive:** Save and share the contact details through Google drive.

You can also share a single contact.

1. Scroll to the required contact and tap the contact to view the contact details.
2. Tap on **Options** and select **Share**.
3. Select the sharing options like Bluetooth, Drive, E-mail, Gmail or Messaging and share the contact.

## Managing Contact Settings

You can set ringtone, enable voice mail, and place the contact on homescreen.

1. From Home screen or **Apps Menu**, tap on **People** ()
2. Scroll to the required contact and tap the contact to view the contact details.
3. Tap on **Options** and select one of the following options:
  - **Set ringtone** to set a specific ringtone for that contact.
  - Enable **All calls to voicemail** to forward all incoming calls from that contact to your voicemail box.
  - Select **Place on Home screen** to place the contact on Home screen for quick access.

## Managing Phonebook Settings

You can sort the contacts to be displayed.

1. From Home screen or **Apps Menu**, tap on **People** ()
2. Tap on **Options > Settings** and select one of the following options:
  - **Sort list by:** Sort the contact names by first name or last name.
  - **View contact names:** You can choose whether the first name has to be displayed first or the last name.

## Searching Contacts

1. From Home screen or **Apps Menu**, tap on **People** ()
2. Tap **Search** () and enter the first few letters/numbers of the contact name/phone number to be searched.

All the contacts containing the searched text are displayed.

## Deleting a Contact

1. From Home screen or **Apps Menu**, tap on **People** ()  
Scroll to the required contact and tap the contact to view the contact details.
2. Tap on **Options** and select **Delete**.
3. Tap on **OK** to delete the contact.

## Making a Call

- From Home screen or **Apps Menu**, tap on the **Phone** ().
- The Phone screen with **Call history** (  ), **Dial pad** (  ) and **Call Options** (  ) are displayed.

To dial a number use one of the following options:

- Call history:** Tap on the call **History** icon (  ). Tap on the phone icon beside the contact or tap on the contact, and tap on the number.
- Dial pad:** Tap on the dial pad. The numeric touch keypad is displayed. Enter the phone number and tap the phone icon to make a call.

To dial an international number, prefix the phone number with the respective country code.

- Frequently called contacts/numbers:** Tap the specific contact/number from the frequently called/ Recieved/Missed numbers list to make a call.

## Calling a Number Via People

- From Home screen or **Apps Menu**, tap on the **People** ().
- Scroll to the contact and tap the contact. The contact details are displayed.
- Tap the required phone number to call the contact.

## Answering an Incoming Call

To answer/reject an incoming call, touch the white phone icon (  ) and slide over one of these icons:

Icons	Description
	Answer the call.
	Disconnect the call.
	Disconnect the call and respond with a default text message from a list of response text messages.

## Adding a Contact From Phone Screen

- From Home screen or **Apps Menu**, tap on the **Phone** ().
- Tap on **Call options** (  ).
- Tap on **New contact**.
- Enter the contact details and tap on **Done**.

## Viewing All Contacts from Phone Screen

- From Home screen or **Apps Menu**, tap on the **Phone** ().
- Tap on **Call options** (  ).
- Tap on **All contacts**.

## Viewing Call History

- From Home screen or **Apps Menu**, tap on the **Phone** ().

2. Tap on the call **History** icon (  ).
3. Tap on **All** to view all the incoming, outgoing, and missed calls.
4. Tap on **Missed** to view only the missed calls.

### Deleting Call History

1. From Home screen or **Apps Menu**, tap on the **Phone** (  ).
2. Tap the call **History** icon (  ).
3. Tap on **Options** (  ).
4. Tap on **Clear call log** to delete the call history.

### Managing Call Settings

You can change the incoming call ring tone, set phone to vibrate while ringing and also activate voicemail, and other settings in **Call settings** screen.

To view and modify call settings,

1. From Home screen or **Apps Menu**, tap on the **Phone** (  ).
2. Tap on **Call options** (  ).
3. Tap on **Settings**.

### Settings

Your phone uses sounds and vibrations to communicate with you, including ringtones, notifications, alarms, and navigation feedback. You can customize any of these sounds, as well as controlling their volume and the volume for music, videos, games, and other media.

To change the phone ringtone,

1. From the Home screen **Apps Menu**, tap on **Settings** (  ).
2. Tap on **Sound** located under **Device settings**.
3. Tap on Phone ringtone located under **CALL RINGTONE & VIBRATE** and select the required ringtone from the list. Tap **OK** to set the ringtone.

### Setting the Volume

Tap on **Volumes** to set the master volume separately for music, ringtones, notifications, and alarms.

You can also use the physical volume control on the phone to raise or lower the volume of whatever sound is currently playing.

### Activating Vibrate Mode

- To set the phone on vibration mode while ringing, enable **Vibrate when ringing** which is located under **Call Settings > Ringtone & Vibrate**.
- To turn off the vibration mode, disable the **Vibrate when ringing** option.

### Setting Up Your Voicemail

1. From Home screen or **Apps Menu**, tap on the **Phone** (  ). tap **Options > Settings**.
2. Tap on **Voicemail** located under **Other Call Settings**.
3. View or enter the following details:
  - **Setup:** Enter your voicemail number.

- **Sound:** Set alert tone for voicemail message
- **Vibrate:** Enable this option to receive a vibrating alert for voicemail messages.

### Dial Pad Touch Tones

1. From Home screen or **Apps Menu**, tap on the **Settings** () , and tap **Sound** ().
2. Enable **Dial pad touch tones** located under **System Settings**.

These tones are played while entering a number in dialpad.

### Editing Quick Responses

The quick responses are the messages that can be used to reject the call with a message.

1. From the Home screen or **Apps Menu**, on the **Phone** () , tap **Options > Settings**.
2. Tap on **Quick responses** located under **Other Call settings**.

The list of quick responses are displayed.

3. Tap on the required quick responses from the list to edit that particular message and tap on **OK** to save the message to the list.
4. While an incoming call arrives, touch the message icon to open a list of quick responses or the option to write your own message. Touch one to send it to the caller immediately and the call gets disconnected.

### Monitoring Fixed Dial Numbers

FDN (fixed dialing numbers) is a SIM card-enabled feature. It restricts outgoing calls only to phone numbers which are listed in the FDN list. This feature can be activated only if PIN2 is entered. Contact your network operator if you do not have a PIN2. Set up your phone to place outgoing calls only to the fixed dialing numbers (FDN) that you save on the phone's SIM card.

1. From the Home screen or **Apps Menu**, tap on the **Phone** () , and tap **Options > Settings**.
2. Tap on **Fixed Dialing Numbers** located under **Other Call Settings**.
3. Tap on **Enable FDN**, and then enter the PIN2 supplied with the SIM card.
4. **Change PIN2** allows you to change the PIN number supplied with the SIM card.
5. Tap on **FDN list** and add numbers. Tap on **Options > Add contact** and enter the details of the contact and tap on **Save**.

### Turn on Proximity Sensor

You can save battery power by switching off the display when you are in a call. Enable Turn on proximity sensor to switch off the display, when you answer a call.

1. From the Home screen or **Apps Menu**, tap on the **Phone** () .
2. Tap **Options > Settings**.
3. Scroll down to select **Turn on proximity sensor** located under **Other call Settings**.
4. Enable **Turn on proximity sensor** to save the

battery power.

## Settings TTY Mode

If you enable TTY mode, hearing-impaired individuals can send and receive phone calls as text over the phone.

1. In the call settings screen, tap **TTY mode** to view and modify TTY mode settings.
2. Set one of the following options:
  - **TTY Off:** disables TTY mode.
  - **TTY Full:** enables TTY mode for both incoming and outgoing calls.
  - **TTY HCO:** enables TTY mode only for incoming calls.
  - **TTY VCO:** enables TTY mode only for outgoing calls.

## DTMF Tones

In the call settings screen, tap on **DTMF tones** under **Other call Settings** to set the DTMF tone length to **Normal** or **Long**.

## Other Call Settings

1. From the Home screen or **Apps Menu**, tap on the **Phone** ()
2. Tap **Options > Settings**.
3. Scroll down to locate **Other call Settings**.

The following options are displayed.

## Call Forwarding

You can forward your incoming calls to a number in the contacts or a new number, provided your network operator supports this service. The device can be set to send incoming calls to a specified number.

1. To access call forwarding settings, in the call settings screen under **Other Call Settings**, tap **Call forwarding**.
2. Select one of the following call forwarding options based on the following conditions. Enter a specific number and tap on **Enable**.

Option	Function
<b>Always forward</b>	Forward all incoming calls to a predesignated number.
<b>Forward when busy</b>	Forward calls when your phone is busy.
<b>Forward when unanswered</b>	Forward calls when you do not answer incoming calls.
<b>Forward when unreachable</b>	Forward calls when your phone is switched off or is out of coverage area.

## Call Waiting

When call waiting is enabled and the phone is in some other call, the new incoming call is displayed and the user can switch to a new incoming call.

To activate call waiting, in the call settings screen, tap on **Additional settings**. Enable **Call waiting**.

## Internet Call Settings

You can make calls and receive calls over Internet when connected to Wi-Fi network, rather than over your mobile network. To place a call over Internet, phone must be configured to use an Internet calling account.

After you set up the account, placing an Internet call is not different than placing any other call. However, you must be connected to a Wi-Fi network. When you are making an Internet call, the phone displays Internet Call near the top of the screen.

## SIP Accounts

Internet calling is based on the Session Initiation Protocol (SIP) for voice calls on Internet Protocol (IP) network.

To add a SIP account and configure your incoming and outgoing preferences:

1. From the Home screen or **Apps Menu**, tap on the **Phone** () .
2. Tap on **Options > Settings**.
3. Scroll down to select **SIP Accounts** located under **Internet call Settings**.
4. Tap **Add Account** to create a new SIP account. Enter the required information and tap **Save** to create a new account.
5. Enable **Receive Incoming Calls** to receive an incoming call from Internet.

## Use Internet Calling

1. From the Home screen or **Apps Menu**, tap on **Phone** () .

2. Tap **Options > Settings**.
3. Scroll down to select **Use Internet Calling** located under **Internet call Settings**.
4. A dialog is open with the following options:
  - **For all calls when data network is available:** If this option is selected and when the phone is connected to Wi-Fi network or mobile Internet, each dialed call becomes an Internet call.
  - **Only for Internet calls:** If this option is selected, only Internet call can be dialed.
  - **Ask for each call:** If this option is selected, when a number is selected to dial, a dialog is displayed to select either **Cell phone call** or **Internet call**.

SMS and MMS are convenient and inexpensive means of communication. You can send a text message to other people via SMS service. MMS allows you to send messages by including multimedia content such as pictures, audio files, video files, and so on.

You can use the **Messaging** in your phone to send an SMS and MMS message to other mobile phones or any other equipment that can receive SMS and MMS.



The MMS feature is available only if you subscribe it from your network operator.

To access the message function, from the home screen or All applications screen, tap on **Messaging** (  ).

### Sending SMS/MMS Message

You can send SMS and MMS messages to contacts in your phonebook and to new numbers that are not present in the phonebook.

1. To create a SMS message, from the home screen or **Apps Menu**, tap on **Messaging** (  ).

2. Tap on **New message** (  ).

3. Enter the contact name or the phone number in the **To** field.

If you enter an alphabet, all the contact names starting with that alphabet and containing that alphabet are displayed as a list. Scroll down to select the contact.

4. Enter the message and tap on **Send** (  ).

When you add an attachment, the message is automatically converted to a multimedia message. MMS charges will apply, based on the operator.

5. To add an attachment, tap on **Attach** (  ). Select the attachment type from the following options.

Browse to a specific folder and select the multimedia file to be attached.

Attachment Type	Description
<b>Pictures</b>	Attach a photo from the phone memory.
<b>Capture picture</b>	Take a new photo using the mobile camera and attach.
<b>Videos</b>	Attach a video from the phone memory.
<b>Capture video</b>	Take a new video using the camcorder and attach.
<b>Audio</b>	Attach an audio file from the phone memory.
<b>Record audio</b>	Record a new audio using the sound recorder and attach.
<b>Slideshow</b>	Create new slideshow or edit the existing slides and attach.
<b>Contact Vcard</b>	Attach a contact available in the phone.

## Managing Message Settings

You can customize the way you want to view and filter the messages. You can also set the default messaging application.

To view and modify the message settings,

1. To edit message settings, from the home screen or All applications screen, tap on **Messaging** (  ).
2. Tap on **Message** options (  ) > **Settings**.
3. View and edit the following settings:

Settings	Description
<b>SMS enabled &gt; Default SMS app</b>	Set the default messaging application.
<b>Delete old messages</b>	Delete the old messages automatically when the storage limit is reached.
<b>Text message limit</b>	Set the maximum number of SMS messages to be stored.
<b>Multimedia message limit</b>	Set the maximum number of MMS messages to be stored.
<b>MMS size limit</b>	Set the MMS size limit.
<b>Notification</b>	Enable notification alert for incoming messages.
<b>Sound</b>	Set the alert tone for incoming messages.

<b>Vibrate</b>	Enable vibrate alert for incoming messages.
<b>Manage SIM card messages</b>	Manages the text messages (SMS) stored in the SIM card.

## Deleting Messages

To delete all the messages,

1. From the home screen or **All Apps Menu**, tap on **Messaging** (  ).
2. Tap on **Message** options (  ).
3. Tap **Delete all Threads**. The complete message thread is deleted after the confirmation.
4. Tap on **Delete** to delete the thread.

To delete an individual conversation, select the conversation to be deleted and tap on **Delete** option and confirm the choice.

## Setting Up E-mail Accounts

You have to configure your e-mail account to access your e-mail box and e-mail services.

1. To create an E-mail account, from the home screen or **Apps Menu**, tap on **Settings** (  ).
2. Tap on **Add account** (  ) which is located under **Accounts** and enter the account credentials and click **Next**.

3. Enter the e-mail address and password. After that, follow on-screen instructions to complete the setup. Also, a new Google account can be created.
4. Select the type of account: **Corporate**, **Google**, or **POP3/IMAP**.
5. To setup another e-mail account, follow the same procedure.

### Sending an E-mail from POP3/IMAP Account

1. Enter the mail recipient in **To** field and subject in the subject line in the **Compose** screen.
2. Enter the message and tap on **Send** ( ➤ ).
3. To add an attachment, tap **Options**. The following are the options:

Option	Description
<b>Attach picture</b>	Attach a photo from the phone memory.
<b>Attach video</b>	Attach a video from the phone memory.
<b>Add Cc/Bcc</b>	Add the recipients in Cc/Bcc.
<b>Save draft</b>	Save the composed mail as a draft.
<b>Discard</b>	Delete the mail.
<b>Settings</b>	Set the general settings.

<b>Insert quick response</b>	Send the required quick responses from the list.
------------------------------	--------------------------------------------------

### Reading an E-mail

1. Select an e-mail account and tap on the **E-mail** to retrieve.
2. To manually retrieve a new e-mail, select **Settings > Accounts >** select a particular account, go to **Options** and tap on **Sync now** icon (  ).
3. Tap a message to read. The following options are available when a message is opened:
  - Reply to the message
  - Forward the message
  - Delete the message
  - Open attachment

## Enter and Edit Text

You can use the virtual Keyboard to enter text quickly and easily. Type faster and more accurately on your device with Keyboard's word recognition and next-word predictions.

The key features are:

- Personalized suggestions, corrections, and completions
- Keypress popup animations
- Gesture Typing with dynamic floating preview
- Voice typing
- Advanced keyboard layouts

## Gesture Typing

1. Tap on the phone screen where you want to type to open the keyboard.
2. Slide your finger slowly across the letters of the word you want to input.
3. Release your finger when the word you want is displayed in the floating preview or in the middle of the suggestion strip. To select one of the words in the suggestion strip, tap on it.

## Use Gesture Typing without the space bar

When you use Gesture Typing, there's no need to use the space bar—just continue to slide your finger across the letters you want to input, then lift your finger to start the next word.

## Keyboard Dictionaries

To manage keyboard dictionaries,

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Tap **Language & Input** located under Personal settings.

### Personal Dictionary

You can add your own words to your personal dictionary so that your device remembers them.

To add a word or phrase, including an optional shortcut,

1. Tap on **Language & Input** located under **Personal** settings.
2. Tap on **Personal dictionary** and then **Add** () icon.
3. Add a required word and respective shortcut which is optional.

### Add-on Dictionary

1. From the Home screen or **Apps Menu**, tap on **Settings** ()
2. Tap on **Language & Input** located under **Personal** settings.
3. Tap on **Settings** () icon next to Google Keyboard.
4. Tap on **Add-on dictionaries**.

The dictionaries for other languages that you can download to your device are displayed.

To avail the AT&T Enhanced PTT (Enhanced Push-To-Talk) services, download the **Google Play** and click on the **EPTT** icon ().

## Downloading Android Applications and Media Files

You can download and install/view your android applications/media files, when your phone is connected to the Internet through Wi-Fi or mobile data connection. You can also download files from Gmail or other sources.

To manage application downloads, tap the **Downloads** icon (  ) located on the **Apps Menu**.

Use the **Downloads** app to view, reopen, or delete the downloaded files.

From the **Downloads** App,

1. Touch an item to open it.
2. Touch headings for earlier downloads to view them.
3. Check items you want to share. Then touch the **Share** icon and choose a sharing method from the list.
4. Check items you want to delete. Then touch the **Trash** icon.
5. At the top of the screen, touch the 3 horizontal lines to sort your downloads by **name**, by **date modified**, or by **size**.

## Accessing Gmail™

Gmail application is used to access your Gmail services.

Google account can be used to sign in to all Google applications and services which includes;

- Google now - for getting the right information at the right time
- Calendar
- People - for keeping track of your accounts

- Google Drive - for working with documents

While reading a message, user can perform **Archive**, **Delete**, **Label**, **Move** and other operations.

## Camera

The Sonim XP7700 has main camera with 8MP (mega pixel) auto focus and a front camera with 1MP (mega pixel) fixed focus for taking pictures. These pictures are saved in **Gallery** (  ) of your phone memory.

You can access **Gallery** from **Apps Menu**.

- To take a picture, press the **Camera** button (yellow button located on the left side of your phone) or tap the **Camera** icon (  ) present in the **Apps Menu**.

The camera screen with touch controls (  ) is displayed.

- Tap on **Camera mode** (  ), to set one of the following modes:
  - **Normal** - (  ): To capture a picture in normal mode, tap the **Capture** icon (  ) to capture the picture. Touch to zoom in and out using the pinch gestures.
  - **Video** (  ): To shoot a video, tap the **Record** icon (  ) to shoot the video. Tap the **Stop** icon (  ) to end the recording. You cannot pause the recording in the middle.
  - **Panoramic** (  ): To capture a picture in panoramic view, tap the **Capture** icon (  ) to capture the picture. Start from the left most edge of the image and move towards the right most edge to capture the complete panoramic image.

To change camera settings (  ) such as flash, exposure, and others, touch the circle to the right of the shutter.

## Multimedia Player

You can play music files and voice memos stored in your phone using the music application.

To play music files,

from **All Apps** screen, tap on **Music** (  ) or tap **Play Music** (  ).

## Calendar

The calendar enables you to set appointments, schedule reminders when required, set alerts and repeat specific settings. Tasks can be viewed on daily and weekly basis.

1. Tap **Apps Menu** (  ) on home screen.
2. Tap on **Calendar** icon (  ) on the Apps screen.
3. To change the calendar view, choose **Day**, **Week**, **Month**, **Agenda** from the top of the screen in a drop-down list.
4. Select **Options** to view the list of available options:
  - **New event:** When Google calendar is synced with your Google account, new event can be generated using the Google account.
  - **Refresh:** Refresh the calendar for the updates.
  - **Search:** You can search for a particular event.
  - **Calendars to display:** Displays the account with which the calendar is synced or not.
  - **Settings:** Displays the **General settings** of the calendar.

From any of the calendar views,

- **Read or edit event details:** Tap on the event to view the details.
- **Manage events and calendar:** Touch icons across the top of the screen or the menu to search or create events, return to today, or adjust settings.

## Alarm

You can set an alarm for a particular time.

1. Tap on **Apps Menu** (  ) on home screen.
2. Tap on the **Clock** icon (  ) located under **Apps**.
3. Tap on the **Alarm** activation icon (  ) on the top of the screen.
4. To set a simple alarm, tap on **Add Alarm** (  ) icon. Enter the time and tap **Done**.
5. To set a reoccurring alarm, enable the checkbox **Repeat**. Select each day in a week by tapping that particular day.
6. To set the alarm tone, tap on **Ringtone** list, select ringtone and tap **OK**.



The alarm works even if the phone is in silent mode.

## Clock

### To adjust clock settings:

1. Open **Clock** app from apps menu.
2. Tap on **Clock** icon (  ).
3. In **Clock**, you can adjust the following options:
  - **Style:** Choose between analog or digital.
  - **Automatic home clock:** Check if you want to add a clock for home while you are traveling.
  - **Home time zone:** Set your home time zone.

## Calculator

The calculator in this phone is designed to perform simple mathematical calculations.

1. Tap on **Apps Menu** (  ) on home screen.
2. Tap on **Calculator** (  ) on the Apps screen.
3. To enter the numbers, tap the numeric keys.
4. To use mathematical operators, touch the respective operation keys on the keypad.
5. After performing the calculations, tap = for the final result.
6. To get the advanced functions, tap on **Option > Advanced panel**.

## Sound Recorder

You can record sound using the sound recorder. To access the sound recorder,

tap **Sound Recorder** (  ) located in **Apps Menu**

screen.

1. To record an audio, tap **Record** (  ).
2. To stop recording, tap **Stop** (  ).
3. To save the voice memo, tap **Save** (  ) .
4. To exit without saving, tap **Discard** (  ).
5. To play the recorded sound instantly, tap **Play** (  ).

### Audio Playback

To listen to a recorded audio file, tap on **Menu > APPS > File Explorer** (  ) > **Sound recorder**.

## About Google Search™ and Google Now™

Google Now is nothing but getting just the right information at the right time. Google now do not require any elaborate setting. The information is on your fingertips.

It gives the information about the weather and traffic update before you start your day.

When Google now is activated, it also activates the **Location reporting** and **Location history**.

- **Location Reporting:** allows Google to periodically store and use your device's most recent location data in connection with your Google Account. Location Reporting is a per-device setting.
- **Location History:** allows Google to store a history of your location data from all devices where you are logged into your Google Account and have enabled location reporting.

## Activate Google Now

Google Now can be setup on your phone when you switch On the phone for the first time. You can turn it **ON** and **OFF** at any time.

1. Tap on the **Google Search bar** on a home screen.
2. Touch **Get Google Now** if you do not have already. To access menu for the next step, perform a Google search.
3. Select **Options > Settings** to turn off Google now.

## Use Google Now

To use Google Now, press and hold the Home button.

## Voice Search and Action

You can speak to your phone to search, get directions, send messages and perform other tasks.

To initiate the voice search or voice action, on the home screen, tap on the **Microphone** icon (  ).

After you touch the Microphone icon, Google listens as you speak and initiates the search or action you describe. If voice search do not understand you, it lists some suggestions. Select the one you want from the list.



Spoken answers are supported for English language only.

## Voice Actions

Voice Actions are supported only in English, French, German, Spanish, and Italian languages.

You can use Voice Actions to perform common tasks, such as sending an e-mail or opening an application.

After touching the **Microphone** icon (  ), speak the voice action you want to use.

## License

This wireless device, (the “Device”) contains software owned by Sonim Technologies, Inc. (“Sonim”) and its third party suppliers and licensors (collectively, the “Software”). As user of this Device, Sonim grants you a non-exclusive, non-transferable, non-assignable license to use the software solely in conjunction with the Device on which it is installed and/or delivered with. Nothing herein shall be construed as a sale of the Software to a user of this Device.

You shall not reproduce, modify, distribute, reverse engineer, decompile, otherwise alter or use any other means to discover the source code of the Software or any component of the Software. For avoidance of doubt, you are at all times entitled to transfer all rights and obligations to the Software to a third party, solely together with the Device with which you received the Software, provided always that such third party agrees in writing to be bound by these rules.

You are granted this license for a term of the useful life of this Device. You can terminate this license by transferring all your rights to the Device on which you have received the Software to a third party in writing. If you fail to comply with any of the terms and conditions set out in this license, it will terminate with immediate effect Sonim and its third party suppliers and licensors are the sole and exclusive owner of and retain all rights, title and interest in and to the Software. Sonim, and, to the extent that the Software contains material or code of a third party, such third party, shall be entitled third party beneficiaries of these terms. The laws of Delaware, United States shall govern the validity, construction and performance of this license.

## Comprehensive 3 Year Warranty

- Sonim provides this Comprehensive 3-year warranty for your mobile phone (hereinafter referred to as “Product”).
- To activate the 3-Year comprehensive warranty, register your phone within 30 days at [www.sonimtech.com/register](http://www.sonimtech.com/register) or use the warranty registration application.
- Should your Product need service, please contact your local Sonim Customer Service Center. The online support and country specific contact information can be found at: [www.sonimtech.com/support](http://www.sonimtech.com/support) or e-mail to: [support@sonimtech.com](mailto:support@sonimtech.com)

## Warranty Registration Application (Only available on Smart phones)

- You can register your phone using the Warranty Registration Application on your device.
- This application initiates automatically after first boot up and prompts to register the handset now or later.
- All the mandatory fields have to be filled, some fields such as IMEI and model number are auto populated.
- State and Zip code fields are same as Province and Postal code.
- Once all the mandatory details are submitted, an e-mail confirmation will be sent.
- If not registered, the application will remind the user to register every two days. After ten reminders the user has to register online.

## Our Warranty

Subject to the conditions of this Comprehensive 3 year Warranty Sonim warrants this product to be free from major defects in design, material and workmanship at the time of its original purchase by a consumer, and for a subsequent period of Three (3) years.

## What We Will Do

If during the guarantee period, this product fails to operate under normal use and service, due to defects in design, material or workmanship, Sonim's authorized distributors or service partners, in the country/region where you purchased the product, will repair or replace at the sole discretion of Sonim, with the same or better model in the same or better condition.

Sonim and its service partners reserve the right to charge a handling fee if a returned product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads or other information may be lost when your Sonim Product is repaired or replaced. Sonim does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss.

You should always make backup copies of all the information stored on your Sonim Product such as downloads, pictures, video's, music, calendar and contacts before handing in your Sonim Product for repair or replacement.

You should always remove SIM cards and MicroSD cards before handing in your Sonim Product for repair or replacement. Depending on local law and legislations we will, in order to protect your data and privacy, destroy any received SIM cards and MicroSD cards.

## Phone Care

Each Sonim Phone has a designated IP class for dust and water protection, according to the IEC Ingress Protection (IP) Standard 60529. This means that the phone is dust protected and can be submerged into 6.5 feet/2 m deep water for up to 30 minutes. Immersion in deeper water can damage it and must be avoided.

Sonim phones are built for heavy duty use. Its design protects against disassembly or mechanical damage when subjected to forces equal to free fall from the height of 6.5 feet/2 meters. Subjecting the phone to stronger impact and forces can damage it and must be avoided.

## Conditions

1. The warranty is valid whether or not the product has been registered.
2. The warranty is valid only if the original proof of purchase issued to the original purchaser by an authorized service provider, specifying the date of purchase and serial number for this Product, is presented with the Product to be repaired or replaced. Sonim reserves the right to refuse warranty service if the device is found to be out of warranty under the conditions as set forth herein.
3. If Sonim repairs or replaces the Product, the repaired or replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sonim.
4. This warranty does not cover any failure of the

Product due to normal wear and tear, or due to misuse or abuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sonim device specifications and instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to software or hardware modification or adjustment, acts of good or damage resulting from liquid interacting with the product beyond what is described as acceptable in the user guide for the product. A rechargeable battery can be charged and discharged hundreds of times. However, it will eventually wear out - this is not a defect. When the talk-time or standby time is noticeably shorter, it is time to replace your battery. Sonim recommends that you use only batteries and chargers approved by Sonim. Minor variations in display brightness and color may occur between phones. There may be tiny bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and cannot be adjusted. Up to three defective pixels are deemed acceptable.

5. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a any person other than a Sonim-authorized person. Tampering with any of the seals on the Product will void the warranty.
6. The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sonim-branded original accessories intended for use with the Product.
7. The 3-year warranty does not cover 3rd party

accessories or any 3rd party software applications, which are instead covered to the extent provided by the original vendor guarantee for these products.

8. THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONIM OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS; TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

### Accessories

Sonim accessories are warranted as follows:

#### Sonim Branded

- All Sonim branded accessories, in-box as well as optional, are warranted for a period of one (1) year under Sonim's 1-Year limited warranty.
- For a detailed list of Sonim branded accessories, please go to: [www.sonimtech.com/accessories](http://www.sonimtech.com/accessories).

#### Battery

All device batteries both embedded and removable are warranted for a period of one (1) year under Sonim's 1-Year limited warranty.

## 1-Year limited warranty

Sonim provides a limited 1-year warranty for this accessory (hereinafter referred to as "Product"). Subject to the conditions of this limited 1-year Warranty Sonim warrants this product to be free from major defects in design, material and workmanship at the time of its original purchase by a consumer, and for a original purchase by a consumer, and for a subsequent period of one (1) year.

### Conditions:

1. This warranty does not cover any failure of the Product due to normal wear and tear, or due to misuse or abuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sonim Product specifications and instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to software or hardware modification or adjustment, acts of good or damage resulting from liquid interacting with the Product beyond what is described as acceptable in the user guide for the Product.
2. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by any person other than a Sonim-authorized person. Tampering with any of the seals on the Product will void the warranty.
3. The warranty does not cover Product failures, which have been caused by use of other peripheral devices, which are not Sonim certified and intended for use with the Product.
4. THERE ARE NO EXPRESS WARRANTIES,

WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONIM OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS; TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

### Sonim XPand

- All Sonim branded accessories, in-box as well as optional, are warranted for a period of three (3) years under Sonim's 3-Year comprehensive warranty.
- For a detailed list of Sonim XPand accessories, please go to: [www.sonimtech.com/accessories](http://www.sonimtech.com/accessories).

**WARNING:** Changes or modifications made to this equipment not expressly approved by Sonim Technologies, Inc. for compliance could void the user's authority to operate the equipment.

### FCC Statement

- This device complies with part 15 of the FCC rules (**FCC ID: WYPL11V012AA**). Operation is subject to the following two conditions:
  - This device may not cause harmful interference.
  - This device must accept any interference received, including interference that may cause undesired operation.
- This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a

circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

### FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### IC Statement

This device complies with RSS-310 of Industry Canada (**IC ID: 8090A-L12V012AA**). Operation is subject to the following two conditions:

1. This device does not cause harmful interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

### FOR PORTABLE DEVICE USAGE (<20cm from body/SAR needed)

#### Radiation Exposure Statement:

The product comply with the Canada portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter, except tested built-in radios. The Country Code Selection feature is disabled for products marketed in the US/ Canada.

- The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;
- High-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices

**A**

- Accessories 60
- Account Sync 39
- Adding a New Contact 41
- Airplane Mode 32
- Alarm 55
- Android Applications
  - Camera 54
- Android Security 35
- Anti-Theft 36

**B**

- Backup 38
- Battery 60
  - Charging indicator 13
- Battery usage
  - Charging 13
  - Improving battery life 14
  - Optimize power 13
- Bluetooth Devices 30
  - Pairing Bluetooth 30
- Bluetooth Tethering 32

**C**

- Calculator 56
- Calendar 55
- Call Barring 47

- Call Forwarding 47
- Camera 54
- Clock 56
- Comprehensive 3 Year Warranty 58
- Credential Certificates 37

**D**

- Data Usage 31
- Deleting a Contact 43
- Device Administrator 37
- Dial Pad 46
- Display Settings 26
- DTMF Tones 47

**E**

- Encrypt 36

**F**

- Face Unlock 35
- FCC Statement 62
- Fixed Dial Numbers 46

**G**

- Gesture Typing 52
- Glove Mode 25

- Gmail 54
- Google Account 18
- Google Account Sync 39
- Google Now 57
- Google Search 57

**H**

- HAC rating 10
- Harmful Applications 37
- Home Screen 19
- Home Screen Indicators 21

**I**

- IC Statement 62
- Internet Calling 48
- Internet Call Settings
  - SIP Account 48

**K**

- Keyboard Dictionaries 52

**L**

- Language 25
- License 58
- Location Access 38

**M**

Memory Usage 28

Microphone 17

Mobile Network 33

Multimedia Player 55

Multi-tool 15

## P

Password 36

Personal Dictionary 52

Phonebook 43

Phone Care 59

Phone specifications 15

POP3/IMAP Account 51

Power Optimization 13

Proximity Sensor 46

PTT Key 17

## Q

Quick Responses 46

## R

Registration Application 58

Reset 38

## S

Security Settings 35

SIM Card 16

SIP Accounts 48

SMS/MMS Message 49

Sound Recorder  
Audio Playback 56

Speech Settings 26

## T

Taking a Screenshot 23

Tethering & Portable Hotspot 32

Time and Date Settings 25

Torch 29

Touch and Type 18

TTY Mode 47

## U

USB Tethering 28

Using Lock Screen  
Face Unlock 22

## V

Vibrate Mode 45

Voice Actions 57

Voice Input 24

Voicemail 45

Voice Search 57

VPN Connection  
Editing VPN 33

## W

Wallpaper 23

Warranty 59

Wi-Fi 32

Wi-Fi Network 30

## X

XP7 Phone 17

## Y

Your SIM 36